

The NB rotary ball spline can be used for both rotational motion and linear motion. It can be used in SCARA robots, the vertical shaft of assembly equipment, and tool changers and loaders.

STRUCTURE AND ADVANTAGES

The NB rotary ball spline consists of a spline shaft and a nut. The nut has a spline portion and a rotating portion using cross rollers.

Reduced Number of Parts:

Because of the single-body construction consisting of the rotating portion and the spline portion, the number of parts is reduced so that the accumulated error is reduced as well.

Compact and Light:

The cross rollers are directly attached to the ball spline's external cylinder, resulting in a compact and light design.

Substantial Reduction in Installation Cost:


The use of cross roller elements keeps the housing thickness to a minimum, making the ball spline light and easy to install.

High Rigidity:

The cross roller elements and 4-row ball circuit structure provides high rigidity in spite of the compact design.

High Accuracy:

The cross roller elements ensure accurate positioning in the rotational direction.



PACIFIC INTERNATIONAL BEARING SALES, INC. 800.228.8895 • WWW.PACIFICBEARINGSALES.COM



PACIFIC INTERNATIONAL BEARING SALES, INC. 800.228.8895 • WWW.PACIFICBEARINGSALES.COM

ACCURACY

The accuracy of the NB rotary ball spline is measured as shown in Figure B-21.

Figure B-21 Accuracy Measurement Points




Table B-15 Tolerance of Spline Shaft Groove Torsion (Max.)

accuracy grade	high		
tolerance	13 µ m/100mm		

The groove torsion is indicated for 100mm, arbitrarily set as the effective length of the spline section. When the motion length is under 100mm or exceeds 100mm, the value shown in Table B-15 increases or decreases proportionally to the motion length.

Table B-16 Tolerance of Parts Relative to Spline Support Area(Max.) unit/ $\mu\,\text{m}$

part number	①radial run out of part attachment area	②perpendicularity of the end of the spline shaft section	③perpendicularity of the flange	
SPR 6	4.4			
SPR 8	14	9	14	
SPR10	17			
SPR13				
SPR16	10	11	18	
SPR20A	19		10	
SPR20				
SPR25A				
SPR25	22	13	21	
SPR30				
SPR40	25	16	25	
SPR50	20	10	20	
SPR60	29	19	29	

Table B-17 ④Radial Run Out of Outer Surface of Rotary Spline Nut Relative to Spline Support Area (Max.)

spline	shaft		part number						
total length		SPR	SPR	SPR	SPR	SPR	SPR		
greater than	or less	6,8	10	13,16	20,20A,25,25A,30	40,50	60		
	200	46	36	34	32	32	30		
200	315	89	54	45	39	36	34		
315	400	126	68	53	44	39	36		
400	500	163*	82	62	50	43	38		
500	630	—	102	75	57	47	41		
630	800	—	—	92	68	54	45		
800	1,000	_	—	115	83	63	51		
1,000	1,250	_	-	153	102	76	59		
1,250	1,600	_	_	195*	130	93	70		
1,600	2,000	_	-	-	171	118	86		

B-33

Contact NB for spline shafts exceeding 2000mm.* SPR6 spline shaft Max. length : 400mm

SPR13,16 Max.length : 1500mm

unit/µm

SLIDE SCREW





PACIFIC INTERNATIONAL BEARING SALES, INC. 800.228.8895 • WWW.PACIFICBEARINGSALES.COM

PRE-LOAD AND CLEARANCE IN ROTATIONAL DIRECTION

The amount of clearance and pre-load for the spline portion and the cross-roller portion are expressed in terms of the clearance in the rotational direction and the clearance in the radial direction, respectively. Three levels of pre-load are available: standard, light (T1), and medium (T2).

	part number	standard	light (T1)	medium (T2)		
	SPR 6	0-11	6	_		
	SPR 8	$-2 \sim +1$	$-6 \sim -2$			
	SPR10					
	SPR13	- 3~+1	-8~-3	-13~-8		
linear motion	SPR16					
	SPR20A					
	SPR20	-4~+2	-12~-4	-20~-12		
	SPR25A					
	SPR25					
	SPR30					
	SPR40			-30~-18		
	SPR50	$-6 \sim +3$	$-18 \sim -6$			
	SPR60					
rotational	SPR 6					
motion	SPR60	±5				
	011100					

Table B-18 Pre-Load and Clearance in Rotational Direction $\mbox{ unit}/\mu\,m$

Table B-19 Operating	Condition	and	Pre-Load
----------------------	-----------	-----	----------

pre-load	symbol	operating condition
standard	blank	Minute vibration is applied. A precise motion is required. Moment is applied in a given direction.
light	T1	Light vibration is applied. Light torsional load is applied. Cyclic torque is applied.
medium	T2	Shock/vibration is applied. Over-hang load is applied. Torsional load is applied.

SPECIAL REQUIREMENTS

NB will fabricate special shaft ends, spline nuts, spline shafts, surface finish etc. to meet customer requirements. Contact NB for details.

Figure B-22 Examples of Shaft End Machining




Table B-20 recommended hollow shaft

part number	outer dia. mm	inner dia. mm	modulus of section mm ³	giometrical moment of inertia mm⁴	
SPR 6	6	2	19.4	58	
SPR 8	8	3	46.5	186	
SPR10	10	4	89.6	448	
SPR13	13	6	193	1,260	
SPR16	16	8	348	2,780	
Contact NB for other sizes.					

PACIFIC INTERNATIONAL BEARING SALES, INC. 800.228.8895 • WWW.PACIFICBEARINGSALES.COM

TOPBALL[®] PRODUCTS

SLIDE UNIT

unit/N • m

SLIDE SCREV

MOUNTING OF ROTARY BALL SPLINE

The flange attachment bolts have been pre-adjusted for smooth rotary movement and should never be loosened. Shock loading to the flange assembly should be avoided as this can degrade the accuracy of movement and deteriorate the overall performance.

Mounting:

When the flange is to be used with a faucet joint (as shown in Figure B-23) the housing bore should be machined to a tolerance of H7 and to a minimum depth of 60% of the flange thickness. If only a light load is applied to the SPR in operation, the flange can be used without a pilot end.

When the mounting bolts are fixed, they should be tightened diagonally in steps with progressively more torque at each step. A torque wrench should be used to achieve uniform torque. The recommended torque values for medium-hardness steel bolts are listed in Table B-21.

Insertion of Spline Shaft:

When inserting the rotary ball spline shaft into the spline nut, ensure that the ball elements do not drop out. This is accomplished by aligning the raceway grooves of the shaft with the rows of ball elements in the nut. Then simply insert the spline shaft through the spline nut.

LUBRICATION

Since NB rotary ball splines are equipped with seals at both the spline portion and the rotational portion, the lubricant is retained for an extended period of time. Lithium soap grease is applied prior to shipment, so they can be used immediately without having to apply lubricant. Lubricant should be added periodically and depending on the operating conditions.

NB also provides low dust generation grease for the linear system. Please refer to page Eng-20 for details. A grease fitting can be installed as an optional feature however, an oil lubricant should be used for highFigure B-23 Flange mounting Method





Table B-21 Recommended Torque

installation bolt	M2	M2.5	M3	M4	M6	M8
recommended torque	0.4	0.9	1.4	3.2	11.2	27.6

(alloy steel bolt)

speed applications. Contact NB for further details.

Figure B-24 Example of Installed Grease Fitting



NB



PACIFIC INTERNATIONAL BEARING SALES, INC. 800.228.8895 • WWW.PACIFICBEARINGSALES.COM

OPERATING ENVIRONMENT

Certain operating environments may prevent the full functionality of the rotary ball spline from being achieved expected accuracies. The operating environment should be taken into consideration when designing the system.


Operating Temperature:

Resin retainers are used in the rotary ball spline, so the operating temperature should never exceed 80°C.

APPLICATION EXAMPLES


Dust Prevention:


The invasion of foreign particles and dust may affect the motion characteristics of the rotary ball spline and shorten the travel life. Seals will perform well under normal operating conditions, but may not completely prevent the entry of dust in a hostile environment. When used in such environments, a dust prevention mechanism such as bellows or covers should be used to protect the rotary ball spline.





PACIFIC INTERNATIONAL BEARING SALES, INC. 800.228.8895 • WWW.PACIFICBEARINGSALES.COM





BALL SPLINE ROTARY BALL SPLIN STROKE BALL SPLIN

TOPBALL® PRODUCTS

SLIDE BUSH

SLIDE UNIT

STROKE BUSH SLIDE ROTARY BUSH

SLIDE SHAFT

SLIDE WAY/GONIO WAY SLIDE TABLE MINIATURE SLIDE

ACTUATOR